Infrastructure HSW Management Sub-System

Roof Inspection Check

Central Southern

To access central southern roof space, enter through the door marked Biometry Hub (offices) turn left and then right (door is located within office), light is on left hand side. To access southern roof space, follow walkway.

Entrance door

Central roof space

Southern roof space

Central Upper

To access central northern roof space, climb the central staircase to the second floor. Directly above you there is a roof hatch with a fixed ladder. Open roof hatch with roof hook (kept in northern area roof space on left hand side of door as you enter). Ascend ladder (light cord on right side) as you climb the ladder).

Roof space

Roof hatch

Roof Details

Roof Material: Terracotta tiles W*55.344 353.@eerrd on right

Warning	This process is uncontrolled when printed. The current version is available on the I&TS Website.	Effective	August 2023	Version:	3.0
Authorised	Director, Capital Projects & Facilities Management Infrastructure Branch Division of University	Review	August 2026	Page: 2 of 3	
Filepath	S:\Services_Resources\Infrastructure\Shared\HSW\01. Hazard Management\01 Roof Access\01	Risk Assessments\W	/aite\2023\Waite B	uilding\WT74 16-0	08-23 Waite